

## **OpDAG** Systems Torque-Trak Revolution Installation Kit Install a Binsfeld's Torque Trak Revolution in few steps !


## Include in the box:

- 1/4" inch Laser cutted « U » bracket  $\checkmark$
- ✓ TT Revo order specific temporary positioner/spacer
- $\checkmark$ Nuts & Bolts bag










Mate the spacer with the shaft and weld the bracket on a previously installed steel beam.

You can also use M13 or ½" bolts option to mate with a non-ferrous structure. (aluminium, fiberglass, etc..)

*Tip : Flip the bracket for a bolted mounting.* 






Remove the plastic spacer.

The bracket is ready to accept the Torque-Trak Revolution unit.


*Tip : This is the best moment to paint the beam and the bracket.* 






Install the Torque-Trak Revolution enclosure by using the 5/16" hardware provided with the kit.

*Tip : This is a close fit tolerance assembly, put all the screws before tightening all the nuts.* 



Please refer to the Torque-Trak Revolution manual for the next steps of the installation.



REVISION 9

